Percent of Wear Adjustment Reference Table (Passenger & Light Truck Tires)

How to Calculate Adjustment Replacement Prices:

1. Determine original tread depth from price list
2. Measure the tire to determine 32nds of tread remaining.
3. Where the 32nds of tread remaining line meets the original tread column, you find the percent of tread worn from the tire.
4. Use this percentage figure to calculate the replacement price,

Example:

1. Original Tread Depth = 12 (12/32)
2. Remaining Tread Depth = 8 (8/32)
3. = 40% Tread Worn
4. 40% x (Replacement Price) = Customer's Discounted Price

Remaining Tread Depth	Original Tread Depth																								
	8	**9**	**10**	**11**	**12**	**13**	**14**	**15**	**16**	**17**	**18**	**19**	**20**	**21**	**22**	**23**	**24**	**25**	**26**	**27**	**28**	**29**	**30**	**31**	**32**
2/32	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%
3/32	83	86	88	89	90	91	92	92	93	93	93	94	94	95	95	95	95	95	96	96	96	96	96	97	97
4/32	67	71	75	78	80	82	83	85	87	88	88	89	89	89	90	90	91	92	92	92	93	93	93	93	93
5/32	50	57	63	67	70	73	75	77	79	80	81	82	83	84	85	86	86	87	88	88	88	89	89	90	90
6/32	33	43	50	56	60	64	67	69	71	73	75	76	78	79	80	81	82	83	83	84	85	85	86	86	87
7/32	17	29	38	44	50	55	58	62	64	67	69	71	72	74	75	76	77	78	79	80	81	81	82	82	83
8/32	0	14	25	33	40	45	50	54	57	60	63	65	67	68	70	71	73	74	75	76	77	78	79	79	80
9/32		0	13	22	30	36	42	46	50	53	56	59	61	63	65	67	68	70	71	72	73	74	75	76	77
10/32			0	11	20	27	33	38	43	47	50	53	56	58	60	62	64	65	67	68	69	70	71	72	73
11/32				0	10	18	25	31	36	40	44	47	50	53	55	57	59	61	63	64	65	67	68	69	70
12/32					0	9	17	23	29	33	38	41	44	47	50	52	55	57	58	60	62	63	64	66	67
13/32						0	8	15	21	27	31	35	39	42	45	48	50	52	54	56	58	59	61	62	63
14/32							0	8	14	20	25	29	33	37	40	43	45	48	50	52	54	56	57	59	60
15/32								0	7	13	19	24	28	32	35	38	41	43	46	48	50	52	54	55	57
16/32									0	7	13	18	22	26	30	33	36	39	42	44	46	48	50	52	53
17/32										0	6	12	17	21	25	29	32	35	38	40	42	44	46	48	50
18/32											0	6	12	16	20	24	27	30	33	36	38	41	43	45	47
19/32												0	6	11	15	19	23	26	29	32	35	37	39	41	43
20/32													0	5	10	14	18	22	25	28	31	33	36	38	40
21/32														0	5	10	14	17	21	24	27	30	32	34	37
22/32															0	5	9	13	17	20	23	26	29	31	33
23/32																0	5	9	13	16	19	22	25	28	30
24/32																	0	4	8	12	15	19	21	24	27
25/32																		0	4	8	12	15	18	21	23
26/32																			0	4	8	11	14	17	20
27/32																				0	4	7	11	14	17
28/32																					0	4	7	10	13
29/32																						0	4	7	10
30/32																							0	3	7
31/32																								0	3
32/32																									0